

VAPORIZER USER MANUAL





PLEASE READ THIS USER MANUAL CAREFULLY BEFORE YOUR FIRST USE













CONTENTS

1- QUICK USER GUIDE

- 1A CHARGE YOUR DEVICE (FULLY)
- 1B TURN DEVICE ON BY CLICKING **BUTTON ON/OFF FIVE TIMES**
- 1C SET THE DESIRED TEMPERATURE (CLICK BUTTON THREE TIMES)

GREEN 3.4 V - BLUE 3.7 V - RED 4.0 V

1D - YOU CAN ALSO PREHEAT THE DEVICE FOR 15 SECONDS BY CLICKING THE BUTTON 2 TIMES.

1E - START VAPING







RED 4.0 V

2 - INTRODUCTION

TSUNAMI WOULD LIKE TO THANK YOU FOR PURCHASING THE SURGE VV DEVICE. WE HOPE YOU ENJOY THE QUALITY AND PERFORMANCE OF YOUR NEW SURGE VV VAPORIZER. TO ENSURE OPTIMAL PERFORMANCE AND SAFETY OF YOUR DEVICE, PLEASE READ THE USER MANUAL FOR INSTRUCTIONS

3 - FEATURES

- 1 650 MAH BATTERY
- 2 MAGNETIC RING
- 3 OIL TANK
- 4 VARIABLE VOLTAGE
- 5 PREHEAT OPTION
- 6 ALL TANKS ADAPTER
- 7 POWER ON/OFF BUTTON
- 8 MICRO US CHARGER
- 9 LED LIGHT



4 - KIT INCLUDES

5 - SPECIFICATIONS

- 1 SURGE VV DEVICE
- 2 MAGNETIC RINGS
- 1 OIL TANK
- 1 ALL SIZES TANK ADAPTER
- 1 MICRO USB CHARGER



CHARGING TIME......2 HOURS

WHEN CHARGING, THE LED LIGHT LOCATED ON THE WINDOW WILL TURN RED. ONCE IT IS FULLY CHARGED, THE LIGHT WILL TURN OFF.

HEATING TIME 10 SECONDS

LOW POWER INDICATIONLED LIGHT FLASHES 10 TIMES

POWER ON/OFFPRESS 5 TIMES IN 2 SECONDS TO TURN ON.
REPEAT THE SAME STEPS TO TURN OFF.

VOLTAGE: GREEN 3.4V BLUE 3.7V RED 4.0V

6 - HOW TO USE

6A - CHARGING THE DEVICE

WARNING:

- 1 TSUNAMI SURGE VV DEVICE SHOULD ONLY BE CHARGED WITH TSUNAMI SURGE VV CHARGER. INCOMPATIBLE CHARGERS MAY CARRY A DIFFERENT VOLTAGE, WHICH MAY BE A FIRE HAZARD. THE USE OF ANY OTHER CHARGERS WILL VOID THE WARRANTY
- 2 TSUNAMI SURGE VV CHARGER CAN ONLY BE USED WITH THE TSUNAMI SURGE VV DEVICE; PLEASE DO NOT USE THIS CHARGER TO CHARGE OTHER ELECTRONIC APPLIANCES
- 3 DO NOT USE THE DEVICE WHILE IT'S CHARGING
- 4 DO NOT LEAVE THE DEVICE CHARGING OVERNIGHT
- 5 IF THE POWER SUPPLY OR THE DEVICE IS FOUND TO BE EMITTING ANY ODOR, TOO HOT, BEING DISCOLORED OR DEFORMED, PLEASE CUT OFF THE POWER SOURCE IMMEDIATELY, AND REMOVE THE DEVICE FROM THE CHARGER AND CONTACT TSUNAMI CUSTOMER SUPPORT
- 6 DO NOT CHARGE OUTSIDE OR IN A DAMP AREA. KEEP OUT OF REACH OF CHILDREN AND PETS
- 7- TSUNAMI IS NOT RESPONSIBLE FOR ANY MISUSE OF THIS PRODUCT

- 1 INSERT THE SURGE VV MICRO USB CHARGER INTO THE MICRO USB PORT IN YOUR SURGE VV DEVICE.
- 2 INSERT THE SURGE MICRO USB CHARGER INTO USB OUTLET.
- 3 WHEN CHARGING THE LED LIGHT LOCATED ON THE WINDOW WILL TURN RED. ONCE FULLY CHARGED. THE LIGHT WILL TURN OFF.
- 4 CHARGING TIME FOR THE SURGE VV DEVICE IS 2 HOURS.

6B - TURN THE DEVICE ON/OFF

NOTE 1: DURING OPERATION, A LOW BATTERY WILL BE INDICATED BY THE LED LIGHT FLASHING 10 TIMES, WHICH MEANS YOU HAVE TO CHARGE THE SURGE VV DEVICE.

NOTE 2: A FULL CHARGE IS RECOMMENDED BEFORE YOUR FIRST USE.

1 - PRESS THE POWER (ON AND OFF BUTTON) FIVE TIMES IN TWO SECONDS, THE SURGE VV UNIT LIGHTS WILL FLASH INDICATING THAT THE DEVICE IS ON



6C - TEMPERATURE AND PREHEAT MODE SETTINGS

CHANGE THE TEMPERATURE BY PRESSING BUTTON THREE TIMES RAPIDLY. THE LED WILL CHANGE TO THE CORRESPONDING TEMPERATURE COLOR

GREEN LED	3.4 V
BLUE LED	3.7 V
RED LED	4.0 V

TO ACTIVATE THE 15 SECOND PREHEATING MODE CLICK THE BUTTON TWO TIMES



7- CLEANING AND MAINTAINING

TURN OFF THE DEVICE BEFORE CLEANING!

NOTE 1: WHILE USING THE DEVICE. PORTIONS OF THE UNIT MAY REACH HIGH TEMPERATURES. DO NOT CLEAN OR DISASSEMBLE THE DEVICE UNTIL ALL PARTS OF THE DEVICE HAVE COOLED COMPLETELY

NOTE 2: DO NOT IMMERSE THE DEVICE IN LIQUID OF ANY KIND; THIS WILL DAMAGE THE HEATING **ELEMENT**

8 - IMPORTANT SAFETY INFORMATION

- 1 INTERNAL PARTS OF THE DEVICE REACH HIGH TEMPERATURES.
- 2 DO NOT DISMANTLE BEYOND CLEANING AND MAINTENANCE; DOING SO WILL VOID THE WARRANTY
- 3 DO NOT USE IF DAMAGED
- 4 USE ONLY PROVIDED POWER SUPPLY TO CHARGE THE SURGE VV DEVICE: THE USE OF ANY OTHER POWER SUPPLY IS DANGEROUS AND WILL VOID THE WARRANTY

9 - STORAGE

11 - ENVIRONMENTAL MISUSAGE (VOIDS WARRANTY)

- 1 STORE THE DEVICE AT LOW TEMPERATURE (BELOW 68 FAHRENHEIT IS RECOMMENDED), LOW HUMIDITY, NO DUST AND NO CORROSIVE GAS ATMOSPHERE
- 2 KEEP THE DEVICE AWAY FROM CHILDREN
 AND PETS TO AVOID ANY ACCIDENTS

10 - ELECTRICAL MISUSAGE (VOIDS WARRANTY)

- 1 USE DEDICATED CHARGER
- 2 DON'T CHARGE THE DEVICE BY A CIGARETTE LIGHTER CHARGER
- 3 DON'T DISASSEMBLE THE DEVICE OR MODIFY THE DESIGN
- 4 DON'T PUT THE DEVICE INTO A MICROWAVE OVEN, DRYER, OR HIGH-PRESSURE CONTAINER
- 5 WHEN CHARGING, KEEP THE CHARGER AWAY FROM HIGHLY FLAMMABLE MATERIALS OR PRODUCTS AND NEVER LEAVE THE CHARGER UNATTENDED WHEN IN USE

- 1 DON'T LEAVE THE DEVICE NEAR FIRE OR A HEATED SOURCE
- 2 DON'T THROW THE DEVICE INTO FIRE
- 3 DON'T LEAVE, CHARGE OR USE THE DEVICE IN A CAR OR SIMILAR PLACE WHERE THE INSIDE TEMPERATURE MAY BE OVER 140 FAHRENHEIT
- 4 DON'T IMMERSE, THROW OR WET THE DEVICE IN WATER / SEAWATER
- 5 DON'T STORE THE DEVICE IN A POCKET OR A BAG TOGETHER WITH METALLIC OBJECTS SUCH AS KEYS, NECKLACES, HAIRPINS, COINS, OR SCREWS.
- 6 DON'T PIERCE THE DEVICE WITH A SHARP OBJECT SUCH AS A NEEDLE.
- 7 DON'T HEAT PARTIAL AREA OF THE DEVICE WITH HEATED OBJECTS SUCH AS SOLDERING IRON.
- 8 DON'T HIT WITH HEAVY OBJECTS SUCH AS A HAMMER OR WEIGHT.

- 9 DON'T STEP ON THE DEVICE OR THROW/ DROP ON THE HARD FLOOR TO AVOID MECHANICAL SHOCK
- 10 STOP USING IF THE DEVICE BECOMES
 ABNORMALLY HOT, ODER EMITS,
 DISCOLORATION, DEFORMATION, OR ABNORMAL
 CONDITIONS ARE DETECTED DURING USE,
 CHARGE OR STORAGE.

KEEP AWAY FROM FIRE IMMEDIATELY WHEN LEAKAGE OR FOUL ODORS ARE DETECTED.

12 - WARRANTY

TO REGISTER YOUR PRODUCT WARRANTY PLEASE VISIT OUR WEBSITE AT **WWW.TSUNAMICARE.COM**

TSUNAMI SURGE INCLUDES A LIFETIME LIMITED WARRANTY THAT STARTS FROM THE DAY OF PURCHASE. THE UNIT MUST BE RETURNED IN ITS ORIGINAL PACKAGING ALONG WITH PROOF OF PURCHASE (RECEIPT)

IF ANY ISSUES ARISE. PLEASE DO NOT RETURN
TO THE RETAILER INSTEAD CONTACT TSUNAMI BY
VISITING OUR WEBSITE AT WWW.TSUNAMICARE.
COM

WHAT IS COVERED

THIS LIMITED WARRANTY COVERS DEFECTS IN MATERIALS AND WORKMANSHIP ON THE SURGE VV BATTERY UNIT ONLY

WHAT ISN'T COVERED

THIS LIMITED WARRANTY DOES NOT COVER ANY DAMAGE, DETERIORATION OR MALFUNCTION RESULTING FROM ANY ALTERATION, MODIFICATION, IMPROPER OR UNREASONABLE USE OR MAINTENANCE, MISUSE, ABUSE, ACCIDENT, NEGLECT, EXPOSURE TO EXCESS MOISTURE, FIRE, POWER SURGES OR OTHER ACTS OF NATURE. THIS LIMITED WARRANTY DOES NOT COVER CARTONS, EQUIPMENT ENCLOSURES, CABLES OR ACCESSORIES USED IN CONJUNCTION WITH THIS PRODUCT. WITHOUT LIMITING ANY OTHER EXCLUSION HEREIN

IF DEFECTIVE, DO NOT RETURN THE PRODUCT TO PLACE OF PURCHASE. WARRANTY IS THROUGH TSUNAMI PREMIUM VAPOR. REGISTER THE WARRANTY ONLINE AT WWW.TSUNAMICARE.COM

IMPORTANT:

PRODUCT/DEFECTIVE PART MUST BE SHIPPED WITH A CHECK OR MONEY ORDER OF \$5.00 PER DEFECTIVE PART; THIS PAYS FOR SHIPPING AND HANDLING. THE UNIT MUST BE RETURNED IN ITS ORIGINAL PACKAGING ALONG WITH PROOF OF PURCHASE (RECEIPT)

WARNING:

USE WITH ONLY LEGAL DRY HERBS OR
BOTANICALS. NOT FOR USE WITH TOBACCO,
LIQUID NICOTINE OR ANY OTHER NICOTINECONTAINING PRODUCTS. MUST BE OF LEGAL
SMOKING AGE AND/OR STATUS TO USE. THIS
PRODUCT IS NOT SUITABLE FOR PEOPLE
UNDER LEGAL SMOKING AGE, PREGNANT OR
BREAST FEEDING, HAVE OR ARE AT RISK OF
HEART DISEASE, HIGH BLOOD PRESSURE,
DIABETES, OR IF YOU ARE TAKING MEDICINES
FOR DEPRESSION OR ASTHMA IF YOU ARE

ALLERGIC TO ANY HERBS OR BOTANICALS OR ANY COMBINATION OF INHALANTS, STOP USING THIS PRODUCT IMMEDIATELY AND SEEK MEDICAL ATTENTION, KEEP OUT OF REACH OF CHILDREN OR PETS. IF YOU FEEL SICK OR IF IRRITATION RESULTS FROM USE, DISCONTINUE USE IMMEDIATELY AND CONSULT A PHYSICIAN. THIS PRODUCT LISED WITH ANY LEGAL DRY HERBS OR BOTANICALS DOES NOT TREAT OR CUTE ANY DISEASE, PHYSICAL AILMENT OR CONDITION. THIS PRODUCT CAN PRESENT A CHOKING HAZARD AND IS NOT MARKETED FOR USE AS A SMOKING CESSATION PRODUCT, THIS PRODUCT AND THE STATEMENTS MADE HEREIN HAVE NOT BEEN APPROVED OR EVALUATED BY ANY HEALTH OR REGULATORY AUTHORITY



