



Power Button:

Powering On - Click the POWER BUTTON five times

Battery Level Check - When the device is off, you can click the power button one time to view the device's battery level. Green signifies a full charge, blue signifies a medium charge, and red signifies that a charge is needed.

Dual Cartridge Setting:

The Tsunami Premium Duo is designed to use one or two cartridges simultaneously or separately. To select which cartridge to operate, push the cartridge shift button. If you have 2 cartridges inserted, this button will help you shift from one cartridge to the other or operate both simultaneously. Follow the corresponding lighting to that particular side of the device. Both lights present indicate both cartridges will operate simultaneously. If you only have 1 cartridge inserted, then only that side will light up and be available for use.

How To Load:

Tsunami Premium Duo is compatible with most 510 threaded carts. Remove the Cartridge Magazine from the body by pulling down. Screw in one or two cartridges, clockwise, until snug. (DO NOT OVERTIGHTEN CARTRIDGES).

Reattach the Cartridge Magazine to the body of the device. When inserted correctly, the indicator light corresponding to the proper cart will light up. If no light, make sure the magnetic connection is solid and the magazine is attached properly.

How To Charge:

Use Type-C USB cable (included with purchase) with most USB wall plugs. Do not let the Tsunami Premium Duo hang while charging as it could damage the charging port.

- Solid Green:** Fully charged, typically 45 min
- Solid Blue:** Medium power, charging
- Solid Red:** Low power, charging


Tips To Clean:

1. Remove and unscrew all carts from device.
2. Wipe cartridge ports clean with 91% isopropyl alcohol using a dampened cotton-tip swab.
3. Wipe any excess oil around the cartridge port and also from the bottom of the cartridges.

Voltage Settings:

When the device is on, you can cycle through 4 different voltage settings by pressing the power button 3 times.

- Green: 2.8V**
- Blue: 3.2V**
- Yellow: 3.7V**
- Red: 4.2V**




Vaping Methods:

Button Press Mode - Simply hold the unit to your lips and press the power button to start vaping. The indicator lights will be present when the button is pressed, and the color of the LED will signify your current voltage setting.

Preheat Mode - A 15-second preheat mode is used to make oils more viscous for a better vaping experience in cold temperatures. To activate, make sure the device is turned on and press the power button two times. The LED band will flash a variety of colors for 15 seconds. When the flashing ends, your device is primed and ready to go.

Auto Draw Mode - The Tsunami Premium Duo is enhanced with an auto-draw feature. Simply pull from the mouthpiece to start vaping. No button press is required. During auto draw mode, you will see the lights on the light indicator light up when drawing from the unit. Some oils may be too thick to operate in auto draw mode. If you find this is true, please refer to button press mode.

Water Pipe Mode -



Pull open the SILICONE PLUG on the bottom of the device. Screw in assembled WATER PIPE ADAPTER to bottom of device (unthread the outer adapter for 14mm pipes). Insert proper end of WATER PIPE ADAPTER into downstem on your water pipe. Allow one 15-second preheat cycle (2 button press) to prime the cartridge(s). Start your vaping session by pressing the power button & holding or pull to activate via the auto draw feature.



Looking for an ultra portable vape? **TSUNAMI PREMIUM Surge VV** has you covered!



@TsunamiPremium
Visit:
TsunamiPremium.com
for more information